

KTM-FP3 INSTALLATION INSTRUCTIONS

KTM (11-15) SX-F,XC-F,XC,SX 250/350/450, (12-16) XCW, XCF-W, EXC, Husabergs (2013)

HUSKY (14-15) FE,FC,TE,TC 250,300,350,450,501 & (2016) FE,250,350,450,501 & TE,TC 250,300

The wide larger round foot that extends from the part near the mounting hole faces **forward** and lays against the frame cross member. You will need to reuse the oem bushing in the new TM part. Place the star washer on the bolt, then insert through the part & install on frame. Use a little blue Loctite on the bolt and torque to oem specification. **SEE PICTURE BELOW**



KTM (16-up) SXF & XCF & (2017-up) SX,XC, EXC,XC-W

HUSKY (2016) FC 250,350,450. & (2017) ALL MODELS

The wide larger round foot that extends from the part near the mounting hole faces back **toward the rear wheel**. The small foot with the black arrow pointing to it in the picture below faces the front of the bike & lays against the frame. You will need to reuse the oem bushing in the new TM part. Place the star washer on the bolt, then insert through the part & install on frame. Use a little blue Loctite on the bolt and torque to oem specification. **SEE PICTURES BELOW**



We recommend you have an authorized motorcycle dealer/mechanic install this part. Improper installation could possibly cause harm to yourself and others, and your bike. The buyer assumes all personal risk to himself and any or all parties concern upon self-installation. These parts are designed as longer wearing alternatives to the stock part. TM Designworks makes no guarantees whether expressed or implied. If any of these terms or instructions are unsatisfactory to you, please return the part within 10 day of purchase for a full refund. Shipping cost may not be included.